



Sprayed film as protection  
of the outside of the  
windows during facade  
renovation works



[info@white-air.co.uk](mailto:info@white-air.co.uk)



Sprayed OMNIGUARD  
film as protection of  
the inside of windows  
during construction  
works, till the end of  
the jobsite.

Removal OMNIGUARD  
film: after 12 months



[www.white-air.co.uk](http://www.white-air.co.uk)



OMNIGUARD served as  
a protection of the  
aluminium windows



01767 651076



Sprayed film as protection of sanitary during construction.  
Photo above: application of OMNIGUARD on a bathtub

## What do we do ?

White Air spray apply a special formula on onto -

Windows and frames

Sanitary ware

Polished concrete

New or existing Facades

That protects the covered items from scratches and general damage caused on active building sites. Omniguard can be left for up to two years before it has to be removed .

[info@white-air.co.uk](mailto:info@white-air.co.uk)

After application, Omniguard dries to a durable, temporary, peel-off protection film. This film protects the entire windows until the end of the project, when this film is easily peeled off and removed. Omniguard protects against damages caused by plaster and concrete works, grinding discs, ...

Omniguard can be applied on glass windows with PVC and aluminium profiles, both in new and renovation projects, and is suitable for inside and outside applications.

By letting Omniguard dry with the windows slightly open, these windows can be used during construction works without damaging the protective film.

**NEW BUILD**



## Spray Protection



**FAÇADE RENOVATION**