



LSPSonos App


Here is the Apps opening screen which allows you to select a speaker to control. Basic layout changes can be made as far as colors and font sizes go. Also please review text and advise on appropriate wording changes.



Once you select the speaker, you will be taken to the playback screen. Which will look like this if some media item is already assigned to the particular speaker...




From here you can click either the white radio logo button on the current selected station. This will open the radio stations selection view, which look like the following...



You can scroll down through the lists of radio stations available and select the one you want to play or press the back button on Android device to return without changing selection.

If you select a speaker which has no Media assigned. Either due to a timeout or it has been restarted the playback screen will look as follows.



The from here click on the white radio button or the Red Sonos Radio logo will allow you to select a station. Clicking the white speaker button takes you back to the speaker selection page.

As previously discussed the admin in charge of the sites Sonos Controller App, will need to review the Radio Stations available and add them to their My Sonos section of the controller. Once the stations are added into the My Sonos section of the Sonos Controller App (pic below). They will then appear in this App in the Station lineup.

