

56\*54\*25cm

TOP

**WARNING—SHOOTS FLAMING BALLS AND REPORTS**  
CAREFULLY READ OTHER WARNINGS ON SIDE PANEL.

**WARNING**  
MAY RE-IGNITE. SOAK WITH WATER AFTER USE.

**FACE THIS SIDE TOWARDS**  
**SPECTATORS PLEASE**



UN0336 1.4G  
CONSUMER FIREWORKS  
MADE IN CHINA

**WARNING—SHOOTS FLAMING BALLS AND REPORTS**  
CAREFULLY READ OTHER WARNINGS ON SIDE PANEL.

*153*  
*SHOTS*

**WARNING—SHOOTS FLAMING BALLS AND REPORTS**  
CAREFULLY READ OTHER WARNINGS ON SIDE PANEL.

UN0336 1.4G  
CONSUMER FIREWORKS  
MADE IN CHINA

**WARNING—SHOOTS FLAMING BALLS AND REPORTS**  
CAREFULLY READ OTHER WARNINGS ON SIDE PANEL.

*153*  
*SHOTS*

**WARNING—SHOOTS FLAMING BALLS AND REPORTS**  
USE ONLY UNDER CLOSE ADULT SUPERVISION. FOR OUTDOOR USE ONLY. DO NOT HOLD IN HAND. PLACE UPRIGHT AND USE ONLY ON CONCRETE, ASPHALT, OR OTHER HARD, LEVEL SURFACE. THIS ITEM MAY TIP OVER IF USED ON GRASS OR OTHER UNEVEN SURFACES AND SERIOUS INJURY COULD RESULT. NEVER HAVE ANY PART OF YOUR BODY OVER THE DEVICE WHEN LIGHTING THE FUSE. LIGHT FUSE AND GET AWAY. NEVER RELIGHT A FUSE THAT FAILS TO IGNITE THE DEVICE.

