


# Infinity iPad + Monitor Kiosk


## Package Contents




DUFFLE BAG (1)




TV MOUNT KIT (1)




TABLET MOUNT (1)



SNAP TUBES (16)




CROSSBARS (6)




LIT. RACKS (2)


## Assembling the frame



1.) Assemble the frame of the display by connecting each pole to its corresponding number






2.) Attach the two curved top sections to the frame






3.) Add stability to the frame by fastening the crossbar pieces into the open sockets

## Attaching the Graphic



## Installing the Tablet Mount

1.) Adjust the tablet mount to fit your device by loosening the socket cap screws with the provided Allen wrench. Once secured, tighten the screws until snug. The tablet can be mounted either vertically or horizontally.






2.) Place the tablet mount in position on the front of the display, and thread the longer of the two black hexagonal screws through the fabric and frame to meet it. Tighten until snug.









## Installing the Shelving

1.) Place each screw through the provided holes of the graphic banner and fasten them into the frame of the display. The shelving can then be secured to the frame by resting them on top of these screws and tightening.



## Installing the TV Mount



1.) Secure the mounting plate (A) onto the frame of the kiosk by threading all four screws through the holes in the graphic.  
2.) Attach the tv mount arms (B) directly to the back of the TV with the provided screws.

3.) Place the TV (with section B already attached) onto section A (which should already be fixed to the kiosk). Secure the mount by threading the provided screws through the bottom of both tv stand arms.